



## SHIMANO Shoes

Unisex

EURO	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52
US	3.7	4.5	5.2	5.8	6.7	7.6	8.3	8.9	9.7	10.5	11.2	11.8	12.3	13.2	14.2	15.2	16.2
UK	2.5	3.5	4	5	6	6.5	7.5	8	9	9.5	10.5	11.5	12	12.5	13	14	14.5
cm	22.5	23.2	23.8	24.5	25.2	25.8	26.5	27.2	27.8	28.5	29.2	29.8	30.5	31.2	31.8	32.5	33.1